

UNITY BUMPER LIGHT BRACKET DATA

Brackets for Unity Fog Lights and Driving Lights are not packed in the same carton which contains the Light Assembly.

These Brackets are packed in separate cartons—ONE BRACKET TO A CARTON.

When ordering Fog Lights or Driving Lights, always specify an equal number of brackets, on basis of ONE bracket for lights packed SINGLY, and TWO brackets for lights packed in PAIRS.

UNLESS BRACKETS ARE SPECIFIED—WE WILL SHIP "B" BRACKETS.

Extra Bumper Brackets may be ordered, if desired, on basis of \$1.38 list price each, subject to regular parts discount. This gives wider application of your stock of Unity Bumper Mounted Lights, the same as with UNITY SAFETYLIGHTS.

BUMPER BRACKET SPECIFICATIONS FOLLOW:

Unless otherwise specified below, use the "A" Bracket.

MAKE	1949	1948	1947	1942 1946	1941	1940
Anglia.....	B					
Austin.....	A	A				
Buick.....	B	B	B	B	B	A
Cadillac.....	B	B	B	B	B	A
Chevrolet.....	B	B	B	B	A	A
Chevrolet Truck.....	G	G	A	A	A	A
Chrysler.....	B	B	B	B	B	A
Crosley.....	A	A	A	A	A	A
De Soto.....	B	G	G	G	A	A
Dodge.....	B	B	B	B	B	A
" Commercial.....	O2	O2	H	H		
Ford.....	F8	F2	F2	F2	A	A
Ford Trucks.....	O2F	O2F	A	A	A	A
Hudson.....	*	*	B1	B1	F	F
International Truck Model K1-2-3- K5-7 C.O.E.....	M	M	M	M	M	M
" K4 to K8.....	H	H	H	H	H	H
" K10 to K12.....	J	J	J	J	J	J
" K1-2-3, KB1-2-3.....	B	B	B			
Kaiser Frazer.....	B	B	B	B		
Lincoln Zephyr.....				F2L	A	A
" Continental.....	††	††		F2L	A	A

MAKE	1949	1948	1947	1942 1946	1941	1940
Lincoln.....	††	††	††	F2L	A	A
Mercury.....	B	F2	F2	F2	A	A
Morris.....	B					
Nash—Standard.....				G	A	F
" DeLuxe.....				N6	A	F
Nash.....	*	N6	N6			
Oldsmobile.....	AP	*	*	O2	O	A
Packard— " Clipper.....	O2	O2	B	B	B	A
Plymouth.....	B	G	G	G	A	A
Pontiac.....	B	B	B	B	B	A
Prefect.....	B					
Reo Trucks.....	N6	N6	N6	N6	N6	A
Studebaker—Champ. " Comm. " Pres.....	*	*	*	G	B	A
Studebaker Truck.....	N6	A	A	A	A	A
White—6" Bumper Models.....	W	W	W	W	W	A
" —7" Bumper Models.....	W1	W1	W1	W1	W1	A
Willys-American " -Jeep.....	A	A	A	A	A	A
" Jeepster, St.Wagon.....	*	*	*	*		

* Use Flush Mounting Type.

†† Factory Equipped.

UNITY MANUFACTURING CO.

2909 INDIANA AVENUE

CHICAGO 16, ILLINOIS

TURN OVER FOR SAFETYLIGHT BRACKET DATA