

BRACKET SPECIFICATIONS FOR UNITY SAFETYLIGHTS AND No. 780 PANORAMIC MIRROR

BRACKETS are cast in BRASS to fit contours of doors or corner posts without filing or fitting.

INSIDE BRACKET—The No. 3 Universal Inside Bracket is used with practically all Safetylight Brackets listed below.
WHEN ORDERING RIGHT HAND BRACKETS, add suffix R.H. to bracket number, thus—52 R.H.

UNIVERSAL Bracket No. 52 is available for all older models not listed. We advise AGAINST the use of this Bracket where we have a tailored Bracket available. Detailed instructions, template and drill bushing accompany each Bracket Set.

PASSENGER CARS	TUBING LENGTH USED				BRACKETS USED			
	1952	1951	1950	1949	1952	1951	1950	1949
Buick—All Models Series 40.....	A	A	GM	A	D31	D31	D31	12
" " " 50.....	GM	GM	GM	GM	D31	D31	D31	D35
" " " 70.....	GM	GM	GM	GM	D31	D31	D31	D35
" Series 70 Convertible.....	GM	GM	GM	GM	D31	D31	D31	D35
" Estate Wagon.....	GM	GM	GM	GM	D35	D35	D35	D35
" Riviera.....	GM	GM	GM	GM	D31	D31	D31	D35
Cadillac—All Models.....	GM	GM	GM	GM	D31	D31	D31	D35
Chevrolet—Closed & Station Wagon.....	A	A	A	A	D37	D37	D37	D37
" Conv. & Hard Top.....	A	A	A	A	D31	D31	D31	D31
Chrysler—Closed & Station Wagon.....	A	A	A	A	D40	D40	11	11
" Convertible.....	A	A	A	A	11	11	11	11
De Soto—Closed & Station Wagon.....	A	A	A	A	D40	D40	11	11
" Convertible.....	A	A	A	A	11	11	11	11
Dodge—Closed & Station Wagon.....	A	A	A	A	D40	D40	11	11
" Conv. & Roadster.....	A	A	A	A	11	11	11	11
Ford—Closed.....	A	A	A	A	D43	27	27	27
" Conv. & Hard Top.....	A	A	A	A	D44	29	29	29
" Station Wagon.....	A	A	A	A	D43	26	26	26
Henry J.....	A	A	A	A	11	11	11	11
Hudson.....	V	A	A	A	D31	28	28	28
Kaiser—All Models.....	GM	GM	A	A	D39	D39	11	11
Lincoln—H—Closed.....	V	A	A	A	D47	26	26	27
" H—Convertible.....	V	A	A	A	D48	11	11	27
" L—Closed.....	V	A	A	A	D47	26	26	26
" L—Convertible.....	V	A	A	A	D48	11	11	11
Mercury—Closed.....	V	A	A	A	D45	11	11	11
" Hard Top.....	V	A	A	A	D46	11	11	11
" Convertible.....	V	A	A	A	D46	11	11	11
" Station Wagon.....	V	A	A	A	D45	26	26	26
Nash—All Models.....	GM	A	A	A	D49	D38	D38	D38
" Rambler.....	A	A	A	A	85	85	85	85
Olds—76-88 Closed.....	A	A	A	A	D31	D37	D37	D37
" 76-88 Conv., Holiday & Super.....	A	A	A	A	D31	D31	D31	D31
" '98 All Models.....	A	GM	GM	GM	D31	D31	D31	D35
Packard—All Models.....	A	A	A	A	D42	D42	18	18
Plymouth—Closed & Station Wagon.....	A	A	A	A	D40	D40	11	11
" Convertible & Hard Top.....	A	A	A	A	11	11	11	11
Pontiac—Closed & Station Wagon.....	A	A	A	A	D37	D37	D37	D37
" Convertible & Catalina.....	A	A	A	A	D31	D31	D31	D31
Studebaker—All Models.....	A	A	A	A	22	22	22	22
Willlys—Passenger.....	A	A	A	A	11	11	11	11
" Jeep—Station Wagon.....	A	B	B	B	77	77	77	77
" Jeepster.....	B	B	B	B	98	98	98	98

COMMERCIAL VEHICLES	TUBING LENGTH USED				BRACKETS USED			
	1952	1951	1950	1949	1952	1951	1950	1949
Chevrolet Trucks.....	B	B	B	B	25	25	25	25
Diamond T.....	B	B	B	B	66	66	66	66
Dodge—Panel—Pickup.....	A	A	A	A	50	50	50	50
" Power Wagon.....	A	A	A	A	69	69	69	69
" Route Van.....	A	A	A	A	17	17	17	17
Ford—All Models.....	A	A	A	A	66	66	66	66
Federal Trucks.....	A	A	A	A	86	86	86	86
GMC—All Models.....	B	B	B	B	25	25	25	25
International—"L" Model.....	A	A	A	A	66	66	66	66
Mack—E Models.....	A	A	A	A	36	36	36	36
" A & L Models.....	A	A	A	A	87	87	87	87
Reo—Trucks.....	A	A	A	A	87	87	87	87
Studebaker.....	A	A	A	A	12	12	12	12
White—WA-WC.....	A	A	A	A	52	52	52	52
" Model 3000.....	A	A	A	A	25	25	25	25
Willlys—Panel & Pickup.....	A	A	A	A	77	77	77	77
Jeep.....	A	A	A	A	77	77	77	77

Specification sheets covering vehicles not listed are available upon request or specify year, make and model of car concerned.

"A" length — 12" centers; specify reg. No. 50 or No. 125. (OUR STANDARD LENGTH).

"B" length — 10 1/4" centers; specify No. 50 B length or No. 125 B length.

"V" length — 13" centers; specify No. 50 V length or No. 125 V length.

GM length — 14" centers; specify No. 50-GM length or No. 125-GM length.

UNLESS SPECIFIED WE WILL SHIP "A" LENGTH No. 50 OR No. 125.

CENTERS—are the dimensions between center of head housing and handle housing. Where letter "D" appears before bracket number, item is for door mounting installation.

WHERE MIRROR SPOTLIGHT IS DESIRED, MERELY PLACE LETTER "M" BEFORE STOCK NUMBER REQUIRED, i.e., M125, M50, etc.

SEE REVERSE SIDE FOR FOG LIGHT DATA

SPECIFICATIONS FOR 1952 CARS—CONDENSED

1952 CHRYSLER PRODUCTS

Bkt. No.	All Models — "A" Length (Std.)
D40	{ Chrysler, Plymouth De Soto, Dodge Closed Cars
#11	{ Chrysler, Plymouth De Soto, Dodge Conv. & Hard Top
#11	Also Fits — 1951-52 Henry J 1952 Willys Closed

1952 GENERAL MOTORS PRODUCTS

Bkt. No.	"A" Length (Standard)
	{ Buick Series 40 Chevrolet Conv. & Hard Top
D31	{ Oldsmobile — All Models Pontiac Conv. & Catalina
D37	{ Chevrolet Closed Pontiac Closed
	GM Length
D31	{ Buick, All Models except 40 Cadillac, All Models

1952 FORD PRODUCTS

Bkt. No.	"A" Length (Standard)
D43	{ Ford Closed & Station Wagon
D44	{ Ford Convertible & Hard Top
	"V" Length
D45	Mercury Closed
D46	{ Mercury Conv. & Hard Top
D47	Lincoln Closed
D48	{ Lincoln Conv. & Hard Top

Bkt. No.	"A" Length (Standard)
D42	{ 1952 Packard — All Models
22	{ 1952 Studebaker — All Models
85	{ 1952 Nash Rambler — All Models

Bkt. No.	GM Length
D49	{ Nash 1952 — All Models except Rambler
D39	{ Kaiser 1952 — All Models

Bkt. No.	"V" Length
D31	{ Hudson 1952 — All Models

See other side for 1949-1952 bracket and tubing specifications. For older information see Form No. 168 dated May 1951 which covers bracket specifications back to 1929.

UNITY FOG LIGHT BRACKET DATA

Brackets for Unity Fog Lights are not packed in the same carton which contains the Light Assembly. These Brackets are packed in separate cartons—ONE BRACKET TO A CARTON.

When ordering Fog Lights or Driving Lights, always specify an equal number of brackets, on basis of ONE bracket for lights packed SINGLY, and TWO brackets for lights packed in PAIRS.

FOG LIGHT SPECIFICATIONS FOR 1952 CARS—CONDENSED

"B" brackets mount on splash pan. "T" brackets mount through curve top of bumper. These two types of brackets fit almost all 1951-1952 passenger cars and will be shipped unless otherwise specified.

FOG LIGHT BRACKET SPECIFICATIONS FOLLOW:

MAKE	1952	1951	1950	1949	1948	1947	1946	1942	1946
Anglia				B					
Austin				A	A				
Buick—All Models	*	*	*	B	B	B	B		
Cadillac	††	††	††	B	B	B	B		
Chevrolet	B	B	B	B	B	B	B		
Chevrolet Truck	G	G	G	G	G	A	A		
Chrysler	T	T	B	B	B	B	B		
De Soto	T	T	B	B	G	G	G		
Dodge	T	T	B	B	B	B	B		
" Commercial	O2	O2	O2	O2	O2	H	H		
Ford		T	**	F8	F2	F2	F2		
Ford Truck	O2F	O2F	O2F	O2F	O2F	A	A		
Henry J	B	B							
Hudson	T	T	*	*	*	B1	B1		
International Truck									
L Models	NH	NH	NH						
Diamond T	N6	N6	N6	B	B	B	A		
Kaiser, Frazer	B	B	B	B	B	B	B		
Lincoln	T	T	T	††	††	††	††	F2L	
Mercury	T	T	B	B	F2	F2	F2	F2	
Nash	T	T	*	*	N6	N6	N6	N6	
Oldsmobile 60-70-80	T	T	AP	AP	*	*	O2		
" 98	*	*	*	AP	*	*	O2		
Packard	T	T	T	T	T	B	B		
Plymouth	B	B	B	B	G	G	G		
Pontiac	B	B	B	W	B	B	B		
Reo Trucks	N6	N6	N6	B	N6	N6	N6		
Studebaker—Champ				T	N6	*	G		
" Comm				T	*	B	G		
" Pres.					B		††		
Studebaker Truck	N6	N6	N6		A	A	A		
White—6" Bumper Models	W	W	W	N6	W	W	W		
" 7" Bumper Models	W1	W1	W1	W1	W1	W1	W1		
Willys Jeep	A	A	A	A	A	A	A		
" Jeepster, St. Wagon	*	*	*	*	*	*	*		

*Use Flush Mounting Type.
 ††Factory Equipped.
 **Use Special 1950 Ford Fog Light No. 445-JP.

UNITY MANUFACTURING CO.

2909 INDIANA AVENUE

CHICAGO 16, ILLINOIS